

LIB Fires & the "ST@TIC" Cleanup Phase

Ernie Hernandez, Supervising Hazmat Specialist Los Angeles County Fire Dept. Health Hazmat Div. W-I2: February 28, 2024




OVERVIEW

Health Hazmat's Role

- Support (air monitoring)
- Mitigation (re-ignitions)
- Oversight (disposal)

Response Guidelines

- Incident Briefing
- Battery Assessment
- De-energization
- Follow-up
- Disposal
- Incident Reviews





SYLMAR INCIDENT

BRIEFING:

- LA City Fire Jurisdiction
- Aerospace company used battery pack to power mfg. equipment.
- Li-ion (NMC) battery pack
 - 7 modules (840 cells)
 - 9 kWh total energy





Battery Assessment










De-energization








Follow-up & Disposal









DOT PACKAGING

- Damaged, Defective or Recalled (DDRs) LIBs.
 - 49 CFR 173.185(f) or via DOT Special Permit
- Summary:
 - Individual, non-metallic inner packaging that completely encloses the cell or battery.
 - Cushioning material that is non-combustible, electrically non-conductive, and absorbent surrounding the inner packaging.
 - One lithium battery per inner packaging, and only one inner packaging per outer group 1 performance packaging.
 - Forbidden for transportation by aircraft.
- DOT Special Permit
 - Vented container.
 - Inner liner filled with fire suppressant material (e.g. CellBlockEX)
 - Multiple batteries with cushioning.
 - Watt-hour ratings.






AIR MONITORING

Thermal Runaway

- Hydrofluoric acid (HF)
- Carbon monoxide (CO)
- Flammables (methane, ethane, ethylene, hydrogen gas)
- Hydrogen cyanide (HCN)
 - → From plastics.
- Particulates (smoke)



De-Energization

- Hydrogen gas (H₂)
 - 1. LEL, or
 - 2. CO (cross sensitivity)
- Chlorine (Cl₂)
 - → Higher energy LIBs only.
- Volatile organics compounds (VOCs)
 - → need more data.



Lessons Learned - Sylmar

- Fire Agency Coordination
 - LAFD JHAT
- Containers
 - Appropriate sizes
 - Safe storage location
- Air Monitoring
 - Thermal runaway (combustion) vs. De-energization (electrolysis)
- DOT Approved Packaging
 - Damaged, Defective or Recalled (DDRs) lithium-ion batteries.



NISSAN LEAF INCIDENT


BRIEFING:

- LA City Fire Jurisdiction
- Resident used LIBs to power backhouse rental.
- 7 x Li-ion (NMC) modules
 - 56 total pouches
 - 12 kWh total energy





Assessment & De-energization









Follow-up









Disposal







Lessons Learned - Nissan Leaf

Verifying De-energization Process

- 10% NaCl solution seems to be working.
- Terminals need to be exposed but protected from contact.
- Check for visible sign of gas formation (i.e., bubbling, fizzing).
- Continued air monitoring for LEL/CO (head space vs. vented).
- Use multimeter to check voltage, if possible.

Lab Analyses

- 1. De-energizing Solution multiple data sets
 - All below HW thresholds for heavy metals, fluorides, pH, and fish bioassay.
- 2. Fire Water Run-off no lab data but only caustic pH of concern.



RECAP

- Incident Briefing
 - Cause of fire
 - Fire-fighting measures
 - Fire description
- Battery Assessment
 - Audio-visuals
 - Temp reading
 - Air monitoring
 - Battery info

- De-energization
 - Safe location
 - 10% NaCl solution
 - Terminals
 - Venting
 - Time
 - Follow-ups
- Disposal
 - U-waste vs. HW
 - DOT approved



RESOURCES

- 8-hour paid training
- SOP Development
- Two 4-hour in-service trainings
- Equipment purchases
 - SPM Flex, FLIR TICs
- PPE upgrade
 - DuraChem® 200 Suits
- DDR containers
- De-energizing supplies (containers, salt, power tools, material handling equipment, etc.)





STAY ALERT

















Maersk vs. Joe Public – HHM coordinating w/ auto dismantlers.



Any Questions?

Ernie Hernandez

Supervising Hazmat Specialist

LACoFD Health Hazmat

ernie.hernandez@fire.lacounty.gov

(323) 890-4086

⚠ WARNINGDamaged Lithium-ion Batteries



CARE OF

Los Angeles Co. Fire Dept. Health Hazmat Division

Date: 02/28/24

For your safety, please DO NOT DISTURB this container under Quarantine Order pursuant to HSC 25187.6.

For more information, please call (323) 890-4317.

www.ncico.com

CSL-B396

